Bashlin belts are sized using the measurement between the 2 D-Rings on the main portion of the belt **(A)**.



2 D-Ring and 4 D-Ring belts are sized identically.

Measure for summer clothing. If the belt is the correct size, there will be ample adjustment for the relatively limited time it will be used in the colder weather.

If a belt is sized correctly, the hip D-Rings will point straight ahead, and the tongue adjustment will be in the center hole **(B)**.



CORRECTLY SIZED TOOL BELT

USE BASHLIN'S LINEMAN'S SIZING BELT (LSB) (E)

Estimate the correct size of your belt and adjust the LSB to the size you believe your belt should be. LSB

Place the LSB on your hips

at the location where your tool belt is worn (F).


By trial and error, change the length of the LSB until the belt is the correct length, and note the adjusted size of the belt **(G)**.



TO FIND YOUR D-RING SIZE USING A TAPE MEASURE

1. Locate the point where the heel of the hip D-Ring should rest **(C)**.

2. Begin to measure from this point. Measure with a seamstress tape around the buttocks to the same point on the opposite side **(D)**.



USING A TAPE MEASURE

BELT ADJUSTMENT IN INCHES -PER ASTM F887 D Size - In. Minimum Center Hole Maximum Tool Loops 32 D18 36 40 3 D19 33 37 41 3 D20 34 42 3 38 D21 36 40 44 4 D22 37 41 45 4 D23 38 42 46 4 D24 40 44 48 4 D25 41 45 49 4 D26 42 46 50 4 D27 44 48 52 4 D28 45 49 53 4

